

ViewSonic[™] Corporation

ViewPad 7e OTA Firmware Upgrade Instruction Guide

ViewPad 7e OTA Firmware Upgrade Instruction Guide





ViewSonic[™] Corporation

ViewPad 7e OTA Firmware Upgrade Instruction Guide

Index

System Requirement	3
Note	3
Step By Step Install Guide	4



ViewSonic[™] Corporation


ViewPad 7e OTA Firmware Upgrade Instruction Guide

System Requirements

1. ViewPad 7e device
2. Wi-Fi network connected

Note

1. Please DO NOT perform firmware upgrade at a place where the Wi-Fi signal strength is Poor.
2. Please make sure the battery power is more than 30% or the AC adapter is plugged in.




ViewSonic[™] Corporation

ViewPad 7e OTA Firmware Upgrade Instruction Guide

Step By Step Install Guide

1. Go to All Apps > FW Update.
2. Enter FW Update, the software will automatically check whether the current firmware version is the latest one or not.
3. If the current firmware is the latest one, it will show the message "Your current firmware is the most updated version." You do not need to update your ViewPad 7e, please tap Exit to exit FW update.







ViewSonic[™] Corporation


ViewPad 7e OTA Firmware Upgrade Instruction Guide

If it shows the message "No Wi-Fi detected. Please check network connection." It means that the Wi-Fi connection is not working. Please check again.



If the current firmware is not the latest one, it will prompt you to update the firmware. Please tap Next to continue.







ViewSonic[™] Corporation

ViewPad 7e OTA Firmware Upgrade Instruction Guide

4. It will start downloading firmware.



5. After download complete, please confirm the battery power percentage. If the power is more than 30% or the AC adapter is plugged in, please tap Next to start firmware upgrade.






ViewSonic[™] Corporation

ViewPad 7e OTA Firmware Upgrade Instruction Guide

6. The ViewPad 7e will reboot and the firmware will update.




7. After firmware update complete, the device will automatically shut down and the firmware is updated successfully.
8. To confirm the firmware version, please Go to Settings > About device > FW version.



ViewSonic[™] Corporation

ViewPad 7e OTA Firmware Upgrade Instruction Guide

1. Until the ViewSonic logo flashes, release the buttons.
2. The device will automatically start firmware upgrade.



3. After the firmware upgrade successfully, the ViewPad 7e will automatically shutdown. And you can manually boot it up to configure the basic settings.